

RS-M8196F


Motion Control Module

Quick Start
(Version 1.0)



ICP DAS CO., LTD.

3 Hardware Configuration



Name	Description
DC Power	External power input (24V) and RS-232 communication port. RS-232 communications port for the Modbus RTU settings and firmware updates.
Modbus RTU Communication Port	Modbus RTU communications port (RS-485/RS-422/RS-232) °
CN1	Motion control signal port; connect to the DN-8368 series terminal board.
CN2	Universal I/O and FRnet communication ports; connect to the DN-20M terminal board.
Dip Switch	Switch for enabling/disabling the firmware execution. <ul style="list-style-type: none"> Init: Initial mode. Disables firmware execution. This mode is necessary for changing the Modbus RTU settings or firmware update. Run: Firmware execution mode (default). Firmware normal program execution (default). Note: The dip switch setting takes effect after the power has been reset.
Sys(red light)	On: Power is on and firmware is running. Blinking: Power is on but firmware is not running. Off: The power is off.
Tx(yellow)	Flashing: transmitting data via RS-232. Off: No data transmission.
Rx(green)	Blinking: receiving data via RS-232. Off: No receiving data.
NET(green)	On: Ethernet connection Blinking: Modbus RTU data transmission. Off: No data transmission.
MOD(green)	Flashing: firmware is running. On or off: firmware is not running (Dip switch is in “Init” position or I-8196F card is not properly plugged into its slot)
LNK(green)	I-8196F function indicator
RUN(green)	I-8196F function indicator


3.1 Power input and RS-232 port

No	Name	Description	
1	FG	Frame ground	
2	N.C.	Reserved	
3	GND	RS-232	Ground
4	TxD		Transmit data wire
5	RxD		Receive data wire
6	IGND	Electrical ground	
7	+Vs	External power supply DC 24V	



3.2 Modbus RTU communication port

No	Name	Description
1	F.G.	Frame ground
2	Tx+/D+	RS-422 transmit data wire (+)/RS-485 data wire
3	Tx-/D-	RS-422 transmit data wire (-)/RS-485 data wire
4	Rx+	RS-422 receive data wire (+)
5	Rx-	RS-422 receive data wire (-)
6	ISO.GND	RS-232 ground
7	TxD	RS-232 transmit data wire
8	RxD	RS-232 receive data wire



3.3 External terminal board


Port CN1 has to be connected to the "DN-8368" series terminal board and CN2 has to be connected to the "DN-20M" terminal board.

4 Wiring Example

Perform the following these wiring steps:

1. Connect the RS-M8196F to a DC24V power input.
2. Connect the RS-M8196F to PLC communication equipment.
3. Connect one or two DN-8368 series terminal board to the CN1 port. Terminal board connected to the CN1A port defines the Axis 0 ~ 2 and the terminal board connected to CN1B is defines the Axis 3 ~ 5.
4. The pin definition of each axis are described in the DN-8368 User's Manual
5. Connect the DN-20M terminal board to the CN2 port if GPIO or FRnet I/O is needed. Refer to the DN-20M instruction manual for the signal pin definitions.
6. Turn on the power after all the connections are properly connected

4.1 Connecting to servomotor




*When using the LTC signal follow the input voltage setting of the DN-8368UB's jumper JP1 ~ JP3.

4.2 Connect the Modbus RTU communication port


Via RS-232:

Connect the ISO.GND, TxD and RxD pins to the PLC communication equipment (or PC serial port).




Via RS-422:

Connect the Tx+, Tx-, Rx+ and Rx- pins to the PLC communication equipment (or PC serial port).



Via RS-485:


Connect the D+ and D- pins to the PLC communication equipment (or PC serial port).



5 Modbus RTU Communication Parameter Settings


Step 1: Connect PC to serial port (RS-232)

Connect to the RS-M8196F to the PC COM port by using the RS-232 cable (CA-0910). The Tx, Rx and GND pins of CA-0910 have to be connected to the Rx, Tx and GND ports of the RS-M8196F. Connect the other end (9-pin, D-sub connector) to the RS-232 COM port of your desktop/laptop.




Step 2: Set RS-M8196F to Initial Mode

First set the DIP-switch to “Init” position, then power up the RS-M8196F.



Step 3: Execute the configuration tool “COMSetting”



1. Click the drop-down menu and select the PC's COM port number to which the RS-M8196F is connected
2. Click the **Get** button to read the current configuration.
3. Specifies the field value, and then click the **Set** button to change the configuration.
4. Click the **Default** button to restore the default configuration.

Factory default setting:

Baud Rate: 115200

Data Bit: 8

Parity: NONE

Stop Bit: 1


Slave ID: 1

Silent Time: 3

User Silent Time: 0

Modbus Port: 0

Step 4: Switch off the RS-M8196F and set the DIP-switch to "Run".



Step 5: Reset the power. Now the RS-M8196F is using the new configuration.

6 Technical Support

Product website:

http://www.icpdas.com/root/product/solutions/remote_io/machine_automation_io/ethernet_solutions/rs-m8196f.html

ICPDAS product service:

service@icpdas.com