

VP-x231-CE7 Series User Manual

Version 1.0.2 December 2017

Service and usage information for

VP-1231-CE7/VP-4231-CE7/VP-6231-CE7



Written by Tunglu Yu
Edited by Anna Huang

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, not for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2017 by ICP DAS Co., Ltd. All rights are reserved.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

Contact US

If you have any problem, please feel free to contact us.

You can count on us for quick response.

Email: service@icpdas.com

Contents

| | |
|---|-----------|
| CONTENTS..... | 3 |
| 1. INTRODUCTION | 6 |
| 1.1. Features..... | 7 |
| 1.2. Specifications | 8 |
| 1.3. Overview | 10 |
| 1.4. Dimensions..... | 18 |
| 1.5. Companion CD..... | 21 |
| 2. GETTING STARTED..... | 22 |
| 2.1. Mounting the VP-x231-CE7..... | 22 |
| 2.1.1. VP-1231-CE7 Installation | 23 |
| 2.1.2. VP-4231-CE7 Installation | 32 |
| 2.1.3. VP-6231-CE7 Installation | 37 |
| 2.2. Configuring the Boot Mode..... | 43 |
| 2.3. Changing the User Interface Language | 45 |
| 2.4. Using PAC Utility to Manage the VP-x231-CE7..... | 47 |
| 2.5. Using DCON Utility Pro Configure I/O Modules | 48 |
| 3. TOOLS AND TASKS..... | 51 |
| 3.1. PAC Utility..... | 52 |
| 3.1.1. Menu Bar – File..... | 53 |
| 3.1.2. Menu Bar – Help..... | 54 |
| 3.1.3. Property Tab - General..... | 55 |
| 3.1.4. Property Tab – General2..... | 57 |
| 3.1.5. Property Tab – Display | 58 |
| 3.1.6. Property Tab – IP Config | 59 |
| 3.1.7. Property Tab – Network..... | 60 |
| 3.1.8. Property Tab – Device Information..... | 63 |
| 3.1.9. Property Tab – Auto Execution | 64 |
| 3.1.10. Property Tab – Rotary Execution | 65 |
| 3.2. DCON Utility Pro..... | 66 |
| 3.3. TaskMgr..... | 67 |
| 3.4. VCEP | 68 |
| 3.5. Remote_Display | 69 |
| 3.6. SendToCOM..... | 70 |
| 3.7. RegEdit | 71 |
| 3.8. ISQLW35..... | 72 |

| | | |
|-----------|---|------------|
| 3.9. | INotepad..... | 73 |
| 4. | YOUR FIRST VP-X231-CE7 PROGRAM..... | 74 |
| 4.1. | Setting up the Development Environment..... | 74 |
| 4.1.1. | Preparing the Development Tools and Programming Languages | 75 |
| 4.1.2. | Installing the VP-x231-CE7 SDK | 76 |
| 4.2. | First VP-x231-CE7 Program in VB.NET..... | 77 |
| 4.2.1. | Create a new project | 78 |
| 4.2.2. | Specify the path of the PAC reference..... | 81 |
| 4.2.3. | Add the control to the form | 83 |
| 4.2.4. | Add the event handling for the control..... | 85 |
| 4.2.5. | Upload the application to VP-x231-CE7 | 86 |
| 4.2.6. | Execute the application on VP-x231-CE7..... | 88 |
| 4.3. | First VP-x231-CE7 Program in Visual C#..... | 89 |
| 4.3.1. | Create a new project | 90 |
| 4.3.2. | Specify the path of the PAC reference..... | 93 |
| 4.3.3. | Add the control to the form | 95 |
| 4.3.4. | Add the event handling for the control..... | 97 |
| 4.3.5. | Upload the application to VP-x231-CE7 | 98 |
| 4.3.6. | Execute the application on VP-x231-CE7..... | 100 |
| 4.4. | First VP-x231-CE7 Program in Visual C++ | 101 |
| 4.4.1. | Create a new project | 102 |
| 4.4.2. | Configure the Platform | 107 |
| 4.4.3. | Specify the Path of PACSDK library and header files | 108 |
| 4.4.4. | Add the control to the form | 111 |
| 4.4.5. | Add the event handling for the control..... | 114 |
| 4.4.6. | Upload the application to VP-x231-CE7 | 116 |
| 4.4.7. | Execute the application on VP-x231-CE7..... | 118 |
| 5. | I/O EXPANSION MODULES AND SDKS SELECTION | 119 |
| 6. | API RESOURCES AND DEMO REFERENCES | 123 |
| 6.1. | PAC Standard APIs for System Operation..... | 124 |
| 6.1.1. | VB.NET Demos for PAC Standard APIs..... | 125 |
| 6.1.2. | C# Demos for PAC Standard APIs..... | 126 |
| 6.1.3. | Visual C++ Demos for PAC Standard APIs | 127 |
| 6.2. | PAC Standard APIs for I/O Expansion | 128 |
| 6.2.1. | VB.NET Samples for PAC Standard APIs..... | 129 |
| 6.2.2. | C# Samples for PAC Standard APIs..... | 131 |
| 6.2.3. | Visual C++ Samples for PAC Standard APIs | 133 |
| 7. | VP-X231-CE7 UPDATES | 135 |

| | | |
|-----------|---|------------|
| 7.1. | OS Updates..... | 136 |
| 7.1.1. | OS Updates from Eshell | 137 |
| 7.1.2. | OS updates using micro_SD..... | 140 |
| 7.2. | SDK Updates..... | 143 |
| 7.2.1. | SDK Updates for VB.NET or C# | 144 |
| 7.2.2. | SDK Updates for VB.NET or Visual C++ | 145 |
| 8. | VIEWPAC DOWNLOAD CENTER..... | 146 |
| | TIPS & HOW TO | 147 |
| A. | I-8K and I-87K I/O Modules | 148 |
| B. | How to Change the Battery | 149 |
| C. | How to Online Debug the VP-x231-CE7 Program..... | 151 |
| D. | How to Automatically Synchronize VP-x231-CE7 Clock with an Internet Time Server | 156 |
| E. | How to Control the User Account Control in VP-x231-CE7 | 158 |
| E.1. | How to Create a User Account..... | 159 |
| E.2. | How to Use Telnet to Remote Login the ViewPAC from PC | 161 |
| E.3. | How to Remove a User Account from the Login List | 163 |
| F. | How to Use the Services Tool | 164 |
| G. | Application of RS-485 Network | 166 |
| G.1. | Basic RS-485 Network..... | 167 |
| G.2. | Daisy Chain RS-485 Network..... | 168 |
| G.3. | Star Type RS-485 Network | 169 |
| G.4. | Random RS-485 Network..... | 171 |
| G.5. | Master/Slaves Settings..... | 172 |
| G.5.1. | ViewPAC as a Master (default) | 173 |
| G.5.2. | ViewPAC as a Slave: | 174 |
| G.6. | 120Ω Terminating Resistor Settings..... | 176 |
| H. | Revision History | 179 |

1. Introduction

This chapter provides an overview of the VP-x231-CE7 and its components, and introduces the fundamental concepts for user familiar with the VP-x231-CE7.



The VP-x231-CE7 is the new generation Windows CE 7.0 based PAC (Programmable Automation Controller) of ICP DAS. Each VP-x231-CE7 is equipped with a Cortex-A8 (1.0 GHz) CPU running a Windows CE 7.0 operating system, a variant of input/output ports (VGA, USB, Ethernet, RS-232/485), and 3 expansion I/O slots that can be used to integrate high performance I-8K (parallel-type) and I-87K (serial-type) series I/O modules.

Its operating system, Windows CE 7.0, has many advantages, including hard real-time capability, small core size, fast boot speed, and interrupt handling at a deeper level, achievable deterministic control and low cost. Using Windows CE 7.0 in the VP-x231-CE7 gives it the ability to run PC-based Control software such as Visual Basic.NET, Visual C#, Embedded Visual C++, SCADA software, Soft PLC ...etc.

1.1. Features

The VP-x231-CE7 offers the most comprehensive configuration to meet specific application requirements. The following list shows the hardware and software features designed to simplify installation, configuration and application.

Hardware Features

- Powerful CPU module
- Cortex-A8 1.0 GHz CPU
- Memory Size:
 - SDRAM (512 MB)
 - MRAM (128 KB)
 - Flash (256 MB)
 - FRAM (64 KB)
 - microSD card (support up to 32 GB)
- VGA Port x 1, USB 2.0 port x 1, Series port (RS-232/RS-485) x 2
- 64-bit Hardware Serial Number
- Dual Watchdog Timers
- Operating Temperature: -25 ~ +75 °C

Software Features

- Windows Embedded Compact 7.0
- JavaScript and VBScript
- SQL Compact Edition 3.5
- .NET Compact Framework 3.5
- Remote Display
- Rich Software Solution – SDK for Microsoft Studio 2008

1.2. Specifications

The table below summarizes the specifications of the VP-x231-CE7.

| Models | VP-1231-CE7 | VP-4231-CE7 | VP-6231-CE7 |
|-------------------------------|---|--|-------------|
| System Software | | | |
| OS | Windows CE 7.0 | | |
| .Net Compact Framework | 3.5 | | |
| Embedded Service | FTP Server, Web Server (Supports VB script, JAVA script), Embedded SQL Server | | |
| SDK Provided | DII for VC, DII for Visual Studio.Net 2008 | | |
| Multilanguage Support | English, German, French, Spanish, Russian, Italian, Korean, Simplified Chinese, Traditional Chinese | | |
| CPU Module | | | |
| CPU | Cortex-A8 (32-bit and 1.0 GHz) | | |
| SDRAM | 512 MB (DDR3) | | |
| MRAM | 128 KB | | |
| Flash | 256 MB | | |
| EEPROM | 16 KB | | |
| microSD | microSD socket with one microSD card (support up to 32 GB) | | |
| RTC (Real Time Clock) | Provide second, minute, hour, date, day of week, month, year | | |
| 64-bit Hardware Serial Number | Yes, for software copy protection | | |
| Dual Watchdog Timers | Yes (0.8 second) | | |
| LED Indicator | 3 Dual-Color LEDs (PWR, RUN, LAN1, L1, L2, L3; L1 to L3 for user programmable) | 2 Dual-Color LEDs (PWR and RUN) | |
| Rotary Switch | Yes (0 to 9) | | |
| LCD Display | | | |
| Size | 5.7" (4:3) | 10" (4:3) | 15" (4:3) |
| Resolution | 640 x 480 | 800 x 600 | 1024 x 768 |
| Brightness | 400 | | 350 |
| Contrast Ratio | 250:1 | 500:1 | |
| LED Backlight Life (hrs) | 20,000 | | |
| Touch Panel | 4-wire, resistive type; light transmission: 80 % | 5-wire, resistive type; light transmission: 80 % | |


| Communication Interfaces | | | |
|----------------------------------|--|-----------------------------|-----------------------------|
| Ethernet | RJ-45 x 1, 10/100/1000 Base-TX | | |
| USB 2.0 (host) | 1 | 2 | |
| COM 2 | RS-485 (D+, D-; self-tuner ASIC inside); 2500 V _{DC} isolated | | |
| COM 3 | RS-232 (RxD, TxD, CTS, RTS, DSR, DTR, CD, RI and GND); Non-isolated | | |
| Audio | Mic-in and Earphone-out | Earphone-out | Mic-in and Earphone-out |
| I/O Expansion Slots | | | |
| Number of I/O slots | 3 | | |
| Supported types of I/O modules | I-8K and I-87K series I/O Modules | | |
| Mechanical | | | |
| Dimensions (W x H x D), unit: mm | 182 x 158 x 125 | 291 x 229 x 129 | 381 x 305 x 145 |
| Panel Cut-out, unit: mm | 153 x 136 ± 1.0 | 276 x 214 ± 1.0 | 366 x 290 ± 1.0 |
| Ingress Protection | Front panel: IP65 | | |
| Installation | Panel mounting | | |
| Environmental | | | |
| Operating Temperature | -20 °C to +70 °C | | |
| Storage Temperature | -30 °C to + 80 °C | | |
| Ambient Relative Humidity | 10 % to 90 % RH (non-condensing) | | |
| Power | | | |
| Input Range | +10 V _{DC} to +30 V _{DC} | | |
| Redundant Power Inputs | - | Yes | |
| Isolation | 1 kV | | |
| Consumption | 0.3 A @ 24 V _{DC} | 0.45 A @ 24 V _{DC} | 0.65 A @ 24 V _{DC} |

1.3. Overview


The VP-x231-CE7 is equipped with several interfaces and peripherals that can be integrated with external systems. Here is an overview of the components and its descriptions.

VP-1231-CE7


Front View



Side View




Back View



- **LED Indicators**

The VP-1231-CE7 has 3 Dual-Color LED indicators. The details of these LED indicators are as follows:



| LED Indicator | Color | Status | Description |
|---------------|-------|----------|--|
| L1/L2/L3 | Red | On | LED indicators controlled by user Program. |
| | Red | Off | |
| RUN | Green | On | System booted and ready. |
| | Green | Off | BIOS failure. |
| | Green | Blinking | System memory mapped out, formatted or defragmented. |
| PWR | Green | On | System has power applied to it. |
| | Green | Off | System is not powered on. |
| LAN1 | Green | On | Link between system and network. |
| | Green | Off | Network disconnected. |
| | Green | Blinking | Network Access. |

- **Touch Screen**

The VP-1231-CE7 is equipped with a touch screen to touch and change the settings.

- **Programmable Function Keys**

The VP-x231-CE7 provides support for keyboard input. The F1 to F6 function keys can be programmed by the user.

- **Rotary Switch**




Rotary Switch is an operating mode selector. The VP-x231-CE7 has several operating modes, for more detailed information about these operating modes. Please refer to “2.2. Configuring the Boot Mode”

- **I/O Slots**

The VP-x231-CE7 has 3 I/O slots that can be used to integrate high performance parallel I/O modules (high profile I-8K Series) or serial I/O modules (high profile I-87K series).

- **Power Input and Frame Ground**

The VP-x231-CE7 has a terminal with 3 pins, there are 2 pins for power input and a pin for frame ground as follows:



- **Ethernet Port**

The VP-x231-CE7 has an Ethernet port that can be used to connect that can be used to connect the router to the Internet or to other devices.

- **Mic-in and Earphone-out**

The VP-x231-CE7 has a microphone and an earphone jack to the input and output of sound system.

- **USB Port**

The VP-x231-CE7 has a USB 2.0 port that can be used to connect the USB devices such as mouse, keyboard or an external USB hard drive.

- **COM2**

COM2 port provides a connection to external RS-485 devices. The COM2 has 2 pins, as follows:


Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 7, 8

Parity: None, Even, Odd, Mark (Always 1), Space (Always 0)

Stop Bits: 1, 2

FIFO: 16 bytes



- **COM3**

The VP-x231-CE7 has one standard RS-232 serial communication interface port, COM3 (9-pin Sub-D plug connector). The details of this Pin assignment are as follows:

Port Type: Male


Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 5, 6, 7, 8

Parity: None, Even, Odd, Mark (Always 1), Space (Always 0)


Stop Bits: 1, 2

FIFO: 16 bytes




VP-4231-CE7/CP-6231-CE7



Front View



Side View



Rear View



- **LED Indicators**

The VP-4231-CE7/VP-6231-CE7 has 2 Dual-Color LED indicators. The details of these LED indicators are as follows:



| LED Indicator | Color | Status | Description |
|---------------|-------|--------|--------------------------------|
| RUN | Red | On | Booting |
| | Red | Off | System booted and OS ready |
| PWR | Green | On | System has power applied to it |
| | Green | Off | System is not powered on |

- **Touch Screen**

The VP-4231-CE7/VP-6231-CE7 is equipped with a touch screen to touch and change the settings.

- **SD Socket**

The SD socket can be used to restore the VP-4231-CE7/VP-6231-CE7 system and expand the memory up to 32 GB.

- **USB Host Port**

The USB host port allows you to connect a USB-compatible mouse, keyboard, or other plug-and-play peripherals and direct communication between data acquisition system and USB storage device.

- **Rotary Switch**




Rotary Switch is an operating mode selector. The VP-x231-CE7 has several operating modes, for more detailed information about these operating modes. Please refer to “2.2 Configuring the Boot Mode”

- **I/O Slots**

The VP-4231-CE7/VP-6231-CE7 has 3 I/O slots that can be used to integrate high performance parallel I/O modules (high profile I-8K Series) or serial I/O modules (high profile I-87K series).


- **Power Input and Frame Ground**

The VP-4231-CE7/VP-6231-CE7 has a terminal with 5 pins, there are 4 pins for redundant power inputs and a pin for frame ground as follows:



- **Ethernet Port**

The VP-4231-CE7/VP-6231-CE7 has an Ethernet port that can be connected to a computer or device via an Ethernet cable.



| LED Indicator | Color | Status | Description |
|---------------|--------|----------|-------------------------|
| 100M/1G | Orange | On | Network Speed: 1 G |
| | Orange | Off | Network Speed: 10/100 M |
| Link/Act | Green | On | The Link is active |
| | Green | Off | The Link is inactive |
| | Green | Blinking | Network activity |

- **Earphone-out/Mic-in and Earphone-out**

The VP-4231-CE7/VP-6231-CE7 has an earphone/a microphone and an earphone jack to the input/input and output of sound system.

- **USB Port**

The VP-4231-CE7/VP-6231-CE7 has 2 USB 2.0 port that can be used to connect the USB devices such as mouse, keyboard or an external USB hard drive.

- **COM2 (RS-485)**

COM2 port provides a connection to external RS-485 devices. The COM2 has 2 pins, as follows:


Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 7, 8

Parity: None, Even, Odd, Mark (Always 1), Space (Always 0)

Stop Bits: 1, 2

FIFO: 16 bytes



- **COM3 (RS-232)**

The VP-x231-CE7 has one standard RS-232 serial communication interface port, COM3 (9-pin Sub-D plug connector). The details of this Pin assignment are as follows:

Port Type: Male


Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 5, 6, 7, 8

Parity: None, Even, Odd, Mark (Always 1), Space (Always 0)

Stop Bits: 1, 2


FIFO: 16 bytes




1.4. Dimensions

The diagrams below provide the dimensions of the VP-x231-CE7 to use in defining your enclosure specifications. Remember to leave room for potential expansion if you are using other components in your system.


VP-1231-CE7




Top View




Recommended
Panel Cut-Out




Front View





Right Side View




Bottom View




Top Veiw




Front Veiw




Right Side Veiw




Bottom Veiw




Top Veiw




Recommended Panel Cut-Out



Front Veiw




Right Side Veiw



Bottom Veiw

1.5. Companion CD

This package comes with a CD that provides a collection of the software utility, documentation, drivers, demo program and application. The CD contains several subdirectories located in \VP-x231 directory. All of them are listed below.



2. Getting Started

This chapter provides a guided tour of the VP-x231-CE7 installation and configuration that describes the steps needed to download, install, configure, and run the basic procedures for user working with the VP-x231-CE7 for the first time.

2.1. Mounting the VP-x231-CE7

Before you work with the VP-x231-CE7, you should have a basic understanding of hardware specification, such as the dimensions, the usable input-voltage range of the power supply, and the type of communication interfaces.

For more information about the hardware details, see section 1.2., “Specifications.”

For more information about the hardware dimensions, see section 1.4., “Dimensions.”

By hardware mechanism, the VP-x231-CE7 installation guide is divided into two sections, as follows:

1. For VP-1231-CE7 – section 2.1.1. VP-1231-CE7 Installation
2. For VP-4231-CE7 – section 2.1.2. VP-4231-CE7 Installation
3. For VP-6231-CE7 – section 2.1.3. VP-6231-CE7 Installation

2.1.1. VP-1231-CE7 Installation

Here is a brief of the steps to install the VP-1231-CE7.

2.1.1.1. Checking the Package Contents

Before starting any task, please check the package contents. If any of the following package contents are missing or damaged, contact your dealer, distributor.



VP-1231-CE7




RJ-45 Waterproof Assembly



A microSD Card and a microSD to SD Adapter



Touch Pen



Software Utility CD



Screw Driver



Panel clip * 4




M4 x 30L Screw * 4

2.1.1.2. Inserting the I/O Modules


There is a top case on each I/O socket. Before inserting the I/O module you first need to remove it.

Step 1: Unlock the top case of the I/O slot and then remove it



Step 2: Hold the I/O module vertically on a socket and then carefully press the I/O module onto the socket

Step 3: Lock the I/O module



Tips & Warnings




If you do not expand the I/O module full, please keep the top case of the unused slot to protect the backplane from dirt, dust and damage from foreign objects.

2.1.1.3. Installing the RJ-45 waterproof connector assembly

The VP-1231-CE7 is equipped with an RJ-45 waterproof connector to protect the connection in vibrate environment.

The RJ-45 waterproof connector is optional for use with Ethernet port. If you do not need the RJ-45 waterproof connector, you just plug in a regular Ethernet cable.




If you want to use the RJ-45 waterproof connector for protecting the connection, follow the instructions below.


Step 1: Remove the RJ-45 connector from the RJ-45 cable




Step 2: Feed the end of the RJ-45 cable through the (A) sealing nut, (B) rubber sealing insert, (C) cable gland base, (D) clamping ring and (E) panel gasket




Step 3: Wrap the (E) panel gasket around the (D) clamping ring




Step 4: Wrap the (C) cable gland base around the (D) clamping ring




Step 5: Insert the (B) rubber sealing insert into the (D) clamping ring



Step 6: Push the (E) sealing nut forward and Hand-tighten it to seal the assembly




Step 7: Insert the RJ-45 cable into the RJ-45 connector



Step 8: Push the RJ-45 waterproof connector assembly forward



Step 9: Insert the Ethernet cable and screw the RJ-45 waterproof into the receptacle




2.1.1.4. Mounting the VP-1231-CE7

The VP-1231-CE7 can be mounted on a panel of maximum thickness 12 mm. Adequate access space can be available at the rear of the instrument panel for wiring and servicing purposes.


Tips & Warnings




To ensure proper ventilation for the VP-1231-CE7, leave a minimum of 50 mm space between the top and bottom edges of the VP-1231-CE7 and the enclosure panels.




Step 1: Prepare the panel and cut the hole to the specified size




Step 2: Attach the VP-1231-CE7 to the cut-out hole



Step 3: Insert the panel mounting clips into the upper and lower ventilation holes



Step 4: Screw the panel mounting clips to the panel.



Tips & Warnings



Recommended Screw Torque: 3.4 ~ 4.5 kgf-cm.

2.1.1.5. Deploying a Basic VP-1231-CE7 System


The VP-1231-CE7 provides a variety of communication interface to suit a range of application. Here is a simple application for using the VP-1231-CE7.

Step 1: Connect the positive terminal (+) of the power supply to the terminal PWR1/2 and the negative terminal (-) of the power supply to the P.GND

Step 2: Connect the USB mouse or the USB keyboard to the USB port

Step 3: Connect the monitor to the VGA port

Step 4: Connect to PC or the laptop to the LAN port via an Ethernet switch



2.1.2. VP-4231-CE7 Installation

Here is a brief of the steps to install the VP-4231-CE7.

2.1.2.1. Checking the Package Contents


Before starting any task, please check the package contents. If any of the following package contents are missing or damaged, contact your dealer, distributor.



VP-4231-CE7



A microSD card and a micro
SD/SD adapter



Software Utility CD



Touch Pen



Screw Driver



Panel Clip * 4




M4 x 30L Screw * 4


2.1.2.2. Inserting the I/O Modules

There is a top case on each I/O socket. Before inserting the I/O module you first need to remove it.


Step 1: Unlock the top case of the I/O slot and then remove it



Step 2: Hold the I/O module vertically and align the socket and then carefully press the I/O module onto the socket



Step 3: Lock the I/O module



Tips & Warnings



If you do not expand the I/O module full, please keep the top case of the unused slot to protect the backplane from dirt, dust and damage from foreign objects.


2.1.2.3. Mounting the VP-4231-CE7

The VP-4231-CE7 can be mounted on a panel of maximum thickness 5 mm. Adequate access space can be available at the rear of the instrument panel for wiring and servicing purposes.


Tips & Warnings



To ensure proper ventilation for the VP-4231-CE7, leave a minimum of 50 mm space between the top and bottom edges of the VP-4231-CE7 and the enclosure panels.




Step 1: Prepare the panel and cut the hole to the specified size




Step 2: Attach the VP-4231-CE7 to the cut-out hole



Step 3: Insert the panel mounting clips into the upper and lower ventilation holes



Step 4: Screw the panel mounting clips to the panel



Tips & Warnings




Recommended Screw Torque: 3.4 ~ 4.5 kgf-cm.

2.1.2.4. Deploying a Basic VP-4231-CE7 System

The VP-4231-CE7 provides a variety of communication interface to suit a range of application. Here is a simple application for using the VP-4231-CE7.

Step 1: Connect the positive terminal (+) of the power supply to the terminal PWR1/2 and the negative terminal (-) of the power supply to the P.GND

Step 2: Connect the USB mouse or the USB keyboard to the USB port



2.1.3. VP-6231-CE7 Installation

Here is a brief of the steps to install the VP-6231-CE7.

2.1.3.1. Checking the Package Contents

Before starting any task, please check the package contents. If any of the following package contents are missing or damaged, contact your dealer, distributor.



VP-6231-CE7




I/O Socket * 3



A microSD Card and a
microSD to SD Adapter



Touch Pen



Software Utility CD



Screw Driver




Panel clip * 4



M4 x 30L Screw * 4


2.1.3.2. Inserting the I/O Modules

There is a top case on each I/O socket. Before inserting the I/O module you first need to remove it.




Step 1: Use the screw driver to remove the screw and then remove the top case

Step 2: Hold the I/O socket vertically and align the VP-4231-CE7 socket and then carefully press the I/O socket onto the socket



Step 3: Use screw driver to screw tightly the screw

Step 4: Hold the I/O module vertically and align the socket and then carefully press the I/O module onto the socket



Tips & Warnings



If you do not expand the I/O module full, please keep the top case of the unused slot to protect the backplane from dirt, dust and damage from foreign objects.


2.1.3.3. Mounting the VP-6231-CE7

The VP-6231-CE7 can be mounted on a panel of maximum thickness 5 mm. Adequate access space can be available at the rear of the instrument panel for wiring and servicing purposes.

Tips & Warnings




To ensure proper ventilation for the VP-6231-CE7, leave a minimum of 50 mm space between the top and bottom edges of the VP-6231-CE7 and the enclosure panels.




Step 1: Prepare the panel and cut the hole to the specified size


Step 2: Attach the VP-6231-CE7 to the cut-out hole



Step 3: Insert the panel mounting clips into the upper and lower ventilation holes



Step 4: Screw the panel mounting clips to the panel.



Tips & Warnings




Recommended Screw Torque: 3.4 ~ 4.5 kgf-cm.

2.1.3.4. Deploying a Basic VP-6231-CE7 System

The VP-6231-CE7 provides a variety of communication interface to suit a range of application. Here is a simple application for using the VP-6231-CE7.


Step 1: Connect the positive terminal (+) of the power supply to the terminal PWR1/2 and the negative terminal (-) of the power supply to the P.GND

Step 2: Connect the USB mouse or the USB keyboard to the USB port



2.2. Configuring the Boot Mode

The VP-x231-CE7 has several operating modes, which can be selected by a rotary switch.



The table below lists the operation modes available with the VP-x231-CE7.

| Position | Operating Mode |
|----------|-------------------------------|
| 0 | Normal mode (Default) |
| 1 | Safe mode |
| 2 | Debug mode |
| 3 | OS update mode by Ethernet |
| 4 | Reserve |
| 5 | OS update mode by Micro_SD |
| 6 | Reserve (OS Development Mode) |
| 7 ~ 9 | User Mode |

The following is a brief introduction of these modes.

Normal Mode (Default mode)

Normal mode is the default mode of operation and the one you will use most of the time. Use this mode for more tasks and configurations. Programs also are executed in this mode.

Safe Mode

Safe mode is a trouble shooting. The mode loads the minimum required device drivers and system services to boot the VP-x231-CE7.

If you have malicious software or a program caused the VP-x231-CE7 cannot be boot or run the normal mode, you can boot in safe mode to solve the problem.

Debug Mode

Debug mode is a special environment in which program debug functions can be used in addition to normal system functions.

Debug mode is unsupported.

OS Update Mode

OS update mode is a way used to update OS. For more information on updating the VP-x231-CE7 OS image, please refer to section 6.1. OS updates

Reserve → OS Development Mode

The positions 4, 6, of rotary switch are reserved for OS development.

User Mode

The positions 7, 8, 9 of rotary switch are reserved for user's applications.


When VP-x231-CE7 is boot with one of these positions, it is boot at normal mode.

User's application can check the position of the rotary switch position to run at different mode.

2.3. Changing the User Interface Language

The **Regional and Language Settings** is a Windows CE functionality that allows users to change the VP-x231-CE7 user interface with your native language.


Step 1: Click Start menu, point to Settings, click Control Panel, and then click Regional Settings



Step 2: Click User Interface Language tab, choose to your local language, and then click OK button



Step 3: Double-click the PAC Utility on the desktop, and then reboot the VP-x231-CE7 for changes to take effect




2.4. Using PAC Utility to Manage the VP-x231-CE7

The PAC Utility is a collection of the VP-x231-CE7 system tool that allows users to manage and configure the VP-x231-CE7 quickly and easily.


For more detailed information on PAC Utility applications, please refer to “3.1. PAC Utility”

Step 1: Double-click the PAC Utility on the desktop

Step 2: Configure IP address (DHCP), FTP Server, Auto Execution files..., etc




Step 3: Reboot the VP-x231-CE7




2.5. Using DCON Utility Pro Configure I/O Modules

DCON Utility Pro allows users to configure and manage the I/O modules via Ethernet or serial ports (RS-232/RS-485).


Step 1: Double-click the DCON_UTILITY_Pro on the desktop



Step 2: Click the  button



Step 3: Configure the communication settings




Tips & Warnings



The COM port settings for expansion I/O modules are listed below.

COM0 [Backplane]




COM2/3

For more information on these COM port selections, please refer to the specification of the pin assignments in section 1.3. Overview

Step 4: Click the  button

Step 5: Click the module name to configure the I/O module



3. Tools and Tasks


This chapter provides a brief introduction of the VP-x231-CE7 service tools and its benefits.

There are several tools and utilities built-in and designed for use with VP-x231-CE7. Some of these are pre-installed on VP-x231-CE7 and can work directly on VP-x231-CE7, and some of these are supporting tools and can help you to manage the VP-x231-CE7 remotely on a PC.

The following tools are pre-installed on VP-x231-CE7 and can work directly on VP-x231-CE7 that can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

CD:\vp-x231\System_Disk\Tools\


http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/system_disk/tools/



3.1. PAC Utility

PAC Utility is a collection of software applications that enable management and configuration of VP-x231-CE7 system and features.


PAC Utility is subject to change



The PAC Utility includes the following menu bars and property tabs. All of these functions will be explained later.


| Menu bar | Property Tab |
|----------|--------------------|
| File | General |
| Help | General2 |
| | Display |
| | IP Config |
| | Network |
| | Device Information |
| | Auto Execution |
| | Rotary Execution |

3.1.1. Menu Bar – File



| The menus use to | How to use |
|--------------------------|--|
| Reboot | Restarts the VP-x231-CE7 |
| Restore Default Settings | Restore the VP-x231-CE7 settings to its default. |
| Exit | Exits the PAC Utility. |


3.1.2. Menu Bar – Help





| The menus use to | How to use |
|------------------|--|
| About | Displays a dialog box with information about PAC Utility, including the current version and copyright information. |

3.1.3. Property Tab - General

The **General** tab provides functions to configure the task bar, check the status of the battery..., etc.



| The tab use to | How to use |
|-----------------------------------|--|
| Lock or Auto-Hide the taskbar | <p>Auto-Hide the taskbar: Select the Auto Hide check box.</p> <p>Lock the taskbar: Select the Always On Top check box.</p> |
| Auto save or manual save to flash | <p>Auto save to flash: Select the Auto Save To Flash (Default) check box. Any changes made to the VP-x231-CE7 will be saved and only take effect after the VP-x231-CE7 reboots.</p> <p>Manual save to flash: Select the Manual Save to Flash check box. Any changes made to the VP-x231-CE7 will be saved by clicking the Save and Reboot from File menu.</p>  |

| The tab use to | How to use |
|--|--|
| Enable USB autorun | Select the Enable Autorun in plugging USB Disk check box. |
| Enable microSD auotrun | This item is temporarily unavailable. |
| Automatic synchronization of system time | Refer to the Appendix A.2. How to configure the service for automatically synchronizing with the internet time server. |
| Adjust the backlight | <p>Move the slider to the left to decrease the brightness or move the slider to the right to increase the brightness, and then click the Save the settings button.</p>  |

3.1.4. Property Tab – General2


The **General2** tab provides functions to specify the name of the USB disk.



| The tab use to | How to use |
|----------------------------------|---|
| Specify the name of the USB disk | Enter a name in the USB Hard Disk: field |

3.1.5. Property Tab – Display


The **Display** tab provides functions to configure the monitor settings.



| The tab use to | How to use |
|--------------------------------|--|
| Adjust the screen resolution | Move the slider to the left to decrease the resolution or move the slider to the right to increase the resolution, and then click the Apply button. |
| Change the screen refresh rate | Select the desired refresh rate from the Screen refresh rate drop-down list, and then click the Apply button. |

3.1.6. Property Tab – IP Config

The **IP Config** tab provides functions to configure either DHCP (Roaming) or manually configured (Static) network settings and to monitor the MAC address. Generally, DHCP is the default settings, but if you don't have a DHCP server, you must configure the network settings by using manual configuration.




| The tab use to | How to use |
|--------------------------|--|
| Set the network settings | <p>Use DHCP to get IP address: Select the Use DHCP to get IP address option, and then click the Apply button.</p> <p>Assign an IP address: Select the Assign IP address option, and then click the Apply button.</p> |

3.1.7. Property Tab – Network

The **Network** tab comprises three tabs – Access, Login and File Server Settings.

Access

The **Access** tab provides functions to enable/disable the FTP access, enable/disable anonymous FTP access, and configure the FTP and HTTP directory path.




| The tab use to | How to use |
|----------------------------------|---|
| Enable or disable the FTP access | <p>Enable the FTP access: Select the Enable check box in the FTP field, and then click the Apply button.</p> <p>Disable the FTP access: Select the Disable check box in the FTP field, and then click the Apply button.</p> |

| The tab use to | How to use |
|--|---|
| Enable or disable anonymous FTP access | <p>Enable anonymous FTP access: Select the Enable check box in the Allow Anonymous field, and then click the Apply button.</p> <p>Disable anonymous FTP access: Select the Disable check box in the Allow Anonymous field, and then click the Apply button.</p> |
| Set the FTP directory path | Enter a new path in the Set FTP default download directory to: field, and then click the Apply button. |
| Set the HTTP directory path | Enter a new path in the Set HTTP document root directory to: field, and then click the Apply button. |

Login


The **Login** tab provides functions to maintain the FTP accounts.



| The tab use to | How to use |
|---------------------------|--|
| Maintain the FTP accounts | Refer to the Appendix C.1 How to add a user account to remote login the VP-x231-CE7 from PC. |

File Server Settings


The **File Server Settings** tab provides functions to set the SMB server.



| The tab use to | How to use |
|--------------------|---|
| Set the SMB server | Click the Settings button to set the SMB server path. |

3.1.8. Property Tab – Device Information

The **Device Information** tab provides functions to monitor necessary system information of the VP-x231-CE7. The information is the most important note of version control for upgrading system.




3.1.9. Property Tab – Auto Execution

The **Auto Execution** tab provides functions to configure programs running at VP-x231-CE7 startup, it allows users to configure ten execute files at most.

Tips & Warnings




The specific extensions are .exe and .bat, and they are executed in order of program 1, program 2, etc.



| The tab use to | How to use |
|---------------------------------------|---|
| Configure programs running at startup | Click the Browse button to select the execute file which you want, and then click the Apply button. |

3.1.10. Property Tab – Rotary Execution

The **Rotary Execution** tab provides functions to configure programs running at VP-x231-CE7 startup in one of the user defined mode, it allows users to configure ten execute files at most.



| The tab use to | How to use |
|---|---|
| Configure programs running at startup in one of the user defined mode | Click the Browse button to select the execute file which you want, and then click the Apply button. |


3.2. DCON Utility Pro

DCON Utility Pro enables users easily to configure and manage the I/O modules via Ethernet or serial ports (RS-232/RS-485).

For more information on how to use DCON Utility Pro to configure I/O modules, please refer to 2.5. Using DCON Utility Pro to Configure I/O Modules


For more detailed information on DCON Utility application, please refer to:

http://www.icpdas.com/root/product/solutions/software/utilities/dcon_utility_pro.html




3.3. TaskMgr

The TaskMgr is a Windows CE application, which provides real time info on all processes and threads including System threads, similar in appearance to the Windows Task Manager.



3.4. VCEP

ICP DAS VCEP is designed for managing your VP-x231-CE7 anywhere. No matter where you are, ICP DAS VCEP provides a convenient environment on the Desktop PC and lets you control your VP-x231-CE7 remotely.



ICP DAS VCEP is composed of two main components: The **Server** which runs on VP-x231-CE7 and the **Client** which runs on a Desktop PC.

Once a connection is established between the client and server (initiated by the client), the client will periodically send requests for screen updates and send mouse/key click information to the server to simulate.

Each video frame is inter-compressed against the previous frame and then intra-compressed with a modified LZW scheme to minimize the amount of data transmitted from server to client.

For more detailed information on VCEP application, please refer to http://ftp.icpdas.com.tw/pub/cd/winpac_am335x/VP-x231-CE7/pc_tools/vcep/

3.5. Remote_Display

The **Remote Display** allows VP-x231-CE7 to be controlled and monitored from a remote location.

This tool is composed of two parts, a client and a server. The server is a program named cerdisp.exe running on VP-x231-CE7. The client is a PC-based program named cerhost.exe running on the PC.



cerdisp



cerhost


Once a connection is established between the client and server (initiated by the client), the client will periodically send requests for screen updates and send mouse/key click information to the server to simulate.

3.6. SendToCOM

The **SendToCOM** uses the serial port to communicate with expansion module. To use the SendToCOM, you can send data to expansion module through the serial port, and receive data from other device through the serial port.


For more information about these commands for communicating with expansion module, please refer to:

http://www.icpdas.com/root/product/solutions/remote_io/rs-485/i-8k_i-87k/i-8k_i-87k_selection.html#b




3.7. RegEdit

The **RegEdit** provides a hierarchical representation of the registry on a target computer, similar in appearance to the Windows Registry Editor. The standard registry roots are represented; you can add keys beneath a root to point to existing registry keys, or you can add your own keys. Values can be changed for existing keys, or added for new keys, and default keys can be specified. For more information, see Registry Settings Management in Deployment.




3.8. ISQLW35

The **ISQLW35** is a Windows Embedded Compact 7 functionality that implements SQL Server Compact 3.5 Query.



3.9. INotepad

The **INotepad** is a common text-only editor. The resulting files have no format tags or styles.



4. Your First VP-x231-CE7 Program

This chapter provides a guided tour that describes the steps needed to set-up a development environment, download, install, configure for user programming with VP-x231-CE7 modules.

4.1. Setting up the Development Environment

Before writing your first program, ensure that you have the necessary development tool and the corresponding SDKs are installed on your system.

4.1.1. Preparing the Development Tools and Programming Languages

VP-x231-CE7 is a Windows CE-based device that supports three programming languages for developing Windows CE applications.

- Visual Basic.NET
- Visual C#
- Visual C++

Development Tools

VP-x231-CE7 supports the application development with the Professional Edition application of Visual Studio 2008.



Tips & Warnings



There are some updates for Visual Studio 2008 to provide support for Windows Embedded Compact 7.

If you have Professional Edition of Visual Studio 2008 are installed, make sure all of the following package are installed

1. Visual Studio 2008 Service Pack 1

<http://www.microsoft.com/en-us/download/details.aspx?id=10986>

2. Visual Studio 2008 update for Windows Embedded Compact 7

<http://www.microsoft.com/en-us/download/confirmation.aspx?id=11935>

3. Windows Embedded Compact 7 ATL Update for Visual Studio 2008 SP1

<http://support.microsoft.com/kb/2468183/en-us>

4.1.2. Installing the VP-x231-CE7 SDK

The VP-x231-CE7 SDK offers several APIs for customizing the standard features and integrating with other applications, devices and services.

Step 1: Get the latest version of the VP-x231-CE7 SDK, AM335x_WINCE7_SDKV100B03

The VP-x231-CE7 SDK can be found from the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

CD:\VP-x231\SDK\PlatformSDK\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/sdk/platformsdk/

Step 2: Execute the AM335x_WINCE7_SDK_YYYYMMDD.msi

Follow the prompts until the installation process is complete.

Step 3: Execute the VisualStudioDeviceWindowsEmbeddedCompact7

Follow the prompts until the installation process is complete.

4.2. First VP-x231-CE7 Program in VB.NET

The best way to learn programming with VP-x231-CE7 is to actually create a VP-x231-CE7 program.

The example below demonstrates how to create a demo program running on VP-x231-CE7 with VB.NET.

To create a demo program with VB.NET that includes the following main steps:

1. Create a new project
2. Specify the path of the PAC reference
3. Add the control to the form
4. Add the event handling for the control
5. Upload the application to VP-x231-CE7
6. Execute the application on VP-x231-CE7

All main steps will be described in the following subsection.

In this tutorial, we will assume that you have installed VP-x231-CE7 SDK on PC and used the Visual Studio 2008 for application development.


4.2.1. Create a new project

The Visual VB.net project template is a composite control that you use in this example creates a new project with this user control.

Step 1: Start Visual Studio 2008




Step 2: On the File menu, point to New, and then click Project



Step 3: In the Project types pane, expand Visual Basic node and select Smart Device

Step 4: In the list of Templates, select Smart Device Project

Step 5: Specify a name and a location for the application and then click OK



Step 6: In the Target platform, select Windows CE


Step 7: In the .NET Compact Framework version, select .NET Compact Framework Version 3.5.

Tips & Warnings



Windows CE7 only supports .NET Compact Framework Version 3.5, if your application uses .NET Compact Framework Version 2.0 there is no guarantee that the program will function correctly.

Step 8: In the list of templates, select Device Application. Click OK



4.2.2. Specify the path of the PAC reference

The PAC SDK provides a complete solution to integrate with VP-x231-CE7 and it's compatible with Visual C#, Visual Basic.NET and C++. In order to use a component in your application, you must first add a reference to it.

Step1: Get the PACNET.dll




The PACNET.dll can be found from the CD that was provided with the package or by downloading the latest version from ICP DAS web site.


CD:\VP-x231\SDK\PACNET\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/sdk/pacnet/

Step 2: On the Project menu, and then click Add Reference...



Step 3: On the Browse tab and browse to where the PACNET.dll are installed, and then click OK




4.2.3. Add the control to the form


You can drag various controls from the Toolbox onto the form. These controls are not really "live"; they are just images that are convenient to move around on the form into a precise location.

After you add a control to your form, you can use the Properties window to set its properties, such as background color and default text. The values that you specify in the Properties window are the initial values that will be assigned to that property when the control is created at run time.

Step 1: On the Toolbox panel, drag a Button control onto the form




Step 2: On the Properties panel, type Check the SDK version in the Text field



4.2.4. Add the event handling for the control

You have finished the design stage of your application and are at the point when you can start adding some code to provide the program's functionality.

Step 1: Double-click the button on the form



Step 2: Inserting the following code

```
Dim data(30) As Byte
PACNET.Sys.GetSDKVersion(data)
MessageBox.Show(PACNET.MISC.WideString(data))
```

```
Public Class Form1
    Private Sub Button1_Click(ByVal sender As System.Object, ByVal e As EventArgs)
        Dim data(30) As Byte
        PACNET.Sys.GetSDKVersion(data)
        MessageBox.Show(PACNET.MISC.WideString(data))
    End Sub
End Class
```


Tips & Warnings




The "PACNET" of "using PACNET" is case- sensitive.

4.2.5. Upload the application to VP-x231-CE7

VP-x231-CE7 supports FTP server service. You can upload files to VP-x231-CE7 or download files from a public FTP server.



Step 1: On the Build menu, and then click Build [Project Name]




Step 2: Open the browser and type the IP address of VP-x231-CE7

Step 3: Upload the application and the corresponding PACNET.dll files to VP-x231-CE7

Tips & Warnings




For applications programming in C# and VB.net with .net compact framework, when executing these application on VP-x231-CE7, the corresponding PACNET.dll must be in the same directory as the .exe file.



4.2.6. Execute the application on VP-x231-CE7

After uploading the application to VP-x231-CE7, you can just double-click it on VP-x231-CE7 to execute it.



4.3. First VP-x231-CE7 Program in Visual C#

The best way to learn programming with VP-x231-CE7 is to actually create a VP-x231-CE7 program.

The example below demonstrates how to create a demo program running on VP-x231-CE7 with Visual C#.

To create a demo program with Visual C# that includes the following main steps:

1. Create a new project
2. Specify the path of the PAC reference
3. Add the control to the form
4. Add the event handling for the control
5. Upload the application to VP-x231-CE7
6. Execute the application on VP-x231-CE7

All main steps will be described in the following subsection.

In this tutorial, we will assume that you have installed VP-x231-CE7 SDK on PC and used the Visual Studio 2008 for application development.


4.3.1. Create a new project

The Visual C# project template is a composite control that you use in this example creates a new project with this user control.

Step 1: Start Visual Studio 2008




Step 2: On the File menu, point to New, and then click Project



Step 3: In the Project types pane, expand Visual C# node and select Smart Device

Step 4: In the list of Templates, select Smart Device Project

Step 5: Specify a name and a location for the application and then click OK



Step 6: In the Target platform, select Windows CE


Step 7: In the .NET Compact Framework version, select .NET Compact Framework Version 3.5.

Tips & Warnings



Windows CE7 only supports .NET Compact Framework Version 3.5, if your application uses .NET Compact Framework Version 2.0 there is no guarantee that the program will function correctly.

Step 8: In the list of templates, select Device Application. Click OK



4.3.2. Specify the path of the PAC reference

The PAC SDK provides a complete solution to integrate with VP-x231-CE7 and it's compatible with Visual C#, Visual Basic.NET and C++. In order to use a component in your application, you must first add a reference to it.

Step1: Get the PACNET.dll




The PACNET.dll can be found from the CD that was provided with the package or by downloading the latest version from ICP DAS web site.


CD:\VP-x231\SDK\PACNET\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/sdk/pacnet/

Step 2: On the Project menu, and then click Add Reference...



Step 3: On the Browse tab and browse to where the PACNET.dll are installed, and then click OK




4.3.3. Add the control to the form


You can drag various controls from the Toolbox onto the form. These controls are not really "live"; they are just images that are convenient to move around on the form into a precise location.

After you add a control to your form, you can use the Properties window to set its properties, such as background color and default text. The values that you specify in the Properties window are the initial values that will be assigned to that property when the control is created at run time.

Step 1: On the Toolbox panel, drag a Button control onto the form




Step 2: On the Properties panel, type Check the SDK version in the Text field



4.3.4. Add the event handling for the control


You have finished the design stage of your application and are at the point when you can start adding some code to provide the program's functionality.

Step 1: Double-click the button on the form



Step 2: Inserting the following code

```
byte[] data = new byte[30];  
PACNET.Sys.GetSDKVersion(data);  
MessageBox.Show(PACNET.MISC.WideString(data));
```




Tips & Warnings




The "PACNET" of "using PACNET" is case- sensitive.

4.3.5. Upload the application to VP-x231-CE7

VP-x231-CE7 supports FTP server service. You can upload files to VP-x231-CE7 or download files from a public FTP server.



Step 1: On the Build menu, and then click Build [Project Name]




Step 2: Open the browser and type the IP address of VP-x231-CE7

Step 3: Upload the application and the corresponding PACNET.dll files to VP-x231-CE7

Tips & Warnings




For applications programming in C# and VB.net with .net compact framework, when executing these application on VP-x231-CE7, the corresponding PACNET.dll must be in the same directory as the .exe file.



4.3.6. Execute the application on VP-x231-CE7

After uploading the application to VP-x231-CE7, you can just double-click it on VP-x231-CE7 to execute it.



4.4. First VP-x231-CE7 Program in Visual C++

The best way to learn programming with VP-x231-CE7 is to actually create a VP-x231-CE7 program.

The example below demonstrates how to create a demo program running on VP-x231-CE7 with Visual C++.

To create a demo program with Visual C# that includes the following main steps:

1. Create a new project
2. Configure the Platform
3. Specify the path of the PAC reference
4. Add the control to the form
5. Add the event handling for the control
6. Upload the application to VP-x231-CE7
7. Execute the application on VP-x231-CE7

All main steps will be described in the following subsection.

In this tutorial, we will assume that you have installed VP-x231-CE7 SDK on PC and used the Visual Studio 2008 for application development.


4.4.1. Create a new project

The Visual C# project template is a composite control that you use in this example creates a new project with this user control.

Step 1: Start Visual Studio 2008




Step 2: On the File menu, point to New, and then click Project




Step 3: In the Project types pane, expand Visual C++ node and select Smart Device

Step 4: In the list of Templates, select MFC Smart Device Application


Step 5: Specify a name and a location for the application and then click OK




Step 6: On the first page of the wizard, click Next




Step 7: On the next page of the wizard, select AM335x_WINCE7_SDK to be added to the project, and then click Next




Step 8: On the next page of the wizard, select Dialog based, and then click next




Step 9: On the next page of the wizard, click next



Step 10: On the next page of the wizard, click next




Step 11: On the next page of the wizard, click Finish



4.4.2. Configure the Platform

When developing applications by using Visual C++, you must configure the Platform to indicate what platform and device you intend to download the application to. Before you deploy your project, check the platform.

On the Debug configuration toolbar, select Release and select AM335x_WINCE7_SDK(ARMv4I) as shown in the following illustration.




4.4.3. Specify the Path of PACSDK library and header files

The PAC SDK provides the PACSDK library and header files with VP-x231-CE7.

It's compatible with C++. In order to use a component in your application, you must first add a reference to it.

Step 1: On the View menu, and then click Property Pages




Step 2: In left pane, expand Configuration Properties, and then click C/C++

Step 3: In the right pane, choose the following path in the Additional Include Dependencies item

C:\Program Files\Windows CE Tools\SDKs\N2000_WINCE7_SDK\Include\Armv4i


C:\Program Files\Microsoft Visual Studio 9.0\VC\atlmfc\include



Step 4: In left pane, click Linker

Step 5: In the right pane, choose the following path in the Additional Library Dependencies item

C:\Program Files\Windows CE Tools\SDKs\N2000_WINCE7_SDK\Include\Armv4i




4.4.4. Add the control to the form


You can drag various controls from the Toolbox onto the form. These controls are not really "live"; they are just images that are convenient to move around on the form into a precise location.

After you add a control to your form, you can use the Properties window to set its properties, such as background color and default text. The values that you specify in the Properties window are the initial values that will be assigned to that property when the control is created at run time.


Step 1: On the View menu, and then click Resource View




Step 2: In the Resource View Panel, Expand the [Project name].rc file and then expand the Dialog item to click the plug-in dialog



Step 3: On the Toolbox panel, drag a Button control onto the form



Step 4: On the Properties panel, type Check the SDK version in the Caption field



4.4.5. Add the event handling for the control

You have finished the design stage of your application and are at the point when you can start adding some code to provide the program's functionality.

Step 1: Double-click the button on the form




Step 2: Inserting the following code

```
char sdk_version[32];  
TCHAR buf[32];  
pac_GetSDKVersion(sdk_version);  
pac_AnsiToWideString(sdk_version, buf);  
MessageBox(buf,0,MB_OK);
```



Step 2: Inserting the following code into the header area


```
#include "PACSDK.h"
```




```
// SDK_InfoDlg.cpp : implementation file
//
#include "stdafx.h"
#include "SDK_Info.h"
#include "SDK_InfoDlg.h"
#include "PACSDK.h"
#ifdef _DEBUG
```

4.4.6. Upload the application to VP-x231-CE7

VP-x231-CE7 supports FTP server service. You can upload files to VP-x231-CE7 or download files from a public FTP server.




Step 1: On the Build menu, and then click Build [Project Name]




Step 2: Open the browser and type the IP address of VP-x231-CE7

Step 3: Upload the application to VP-x231-CE7



4.4.7. Execute the application on VP-x231-CE7


After uploading the application to VP-x231-CE7, you can just double-click it on VP-x231-CE7 to execute it.



5. I/O Expansion Modules and SDKs Selection

This chapter describes how to select a suitable expansion I/O module and the corresponding SDK library to be used for developing programs on VP-x231-CE7.

VP-x231-CE7 provides the following I/O expansion buses:



1. Local I/O Modules (I-8K series and I-87K series)

VP-x231-CE7 has three expansion slots that can be used to add expansion I/O modules. The expansion I/O modules can be divided into two categories: High Profile I-8K series I/O modules and High profile I-87K series I/O modules. The following indicates the appropriate SDK library to be used for I/O modules.

➤ General I-8K/I-87K series I/O modules

| Module | Native SDK | .NET CF SDK |
|-----------------------|----------------|-------------|
| I-8K series | PACSDK.dll | PACNET.dll |
| I-87K series | PACSDK.dll | PACNET.dll |
| I-8K series with PWM | PACSDK_PWM.dll | PACNET.dll |
| I-87K series with PWM | PACSDK_PWM.dll | PACNET.dll |

For full details regarding I-87K series I/O modules and its demos, please refer to:

http://ftp.icpdas.com/pub/cd/winpac_am335x/demo/vp-x231/pac/applicable_demo_for_87k_module.pdf

➤ Specified I-8K series I/O modules

| Module | Native SDK | .NET CF SDK |
|----------|-----------------|--------------------|
| I-8014W | pac_i8014W.dll | pac_i8014WNET.dll |
| I-8017HW | pac_i8017HW.dll | pac_i8017HWNET.dll |
| I-8024W | pac_i8024W.dll | pac_i8024WNET.dll |
| I-8026W | pac_i8026W.dll | pac_i8026WNET.dll |
| I-8048W | pac_i8048W.dll | pac_i8048WNET.dll |
| I-8050W | pac_i8050W.dll | pac_i8050WNET.dll |
| I-8084W | pac_i8084W.dll | pac_i8084WNET.dll |
| I-8088W | pac_i8088W.dll | pac_i8088WNET.dll |
| I-8093W | pac_i8093W.dll | pac_i8093WNET.dll |
| I-87088W | PACSDK_PWM.dll | PACNET.dll |

2. RS-485 (I-7000 series and M-7000 series)

I-7000, M-7000, RU-87Pn and high profile I-87K series modules connect to VP-x231-CE7 via a twisted-pair, multi-drop, 2-wire RS-485 network.

➤ I-7000 series I/O modules

| Module | Native SDK | .NET CF SDK |
|-------------------------------|----------------|-------------|
| I-7000 series | PACSDK.dll | PACNET.dll |
| I-7000 series with I-7088 (D) | PACSDK_PWM.dll | PACNET.dll |

For full details regarding I-7000 series I/O modules and its demos, please refer to:

http://ftp.icpdas.com/pub/cd/winpac_am335x/demo/vp-x231/pac/applicable_demo_for_7k_module.pdf

➤ M-7000 series I/O modules

| Module | Native SDK | .NET CF SDK |
|---------------|-------------|-------------|
| M-7000 series | Modbus Demo | Modbus Demo |

For more detailed information about M-7000 series modules using Modbus protocol and its demos, please refer to:

CD:\vp-x231\demo\nModbus\

➤ RU-87Pn + I-87K series I/O modules

| Module | Native SDK | .NET CF SDK |
|----------------------|------------|-------------|
| RU-87Pn+I-87K series | PACSDK.dll | PACNET.dll |

➤ Other Specified I/O

| Module | Native SDK | .NET CF SDK |
|--------|------------|-------------|
| Others | PACSDK.dll | PACNET.dll |

3. Ethernet (ET-7000 series and I-8KE4/8-MTCP)

The Ethernet I/O devices available include ET-7000 and I-8KE4/8-MTCP, and support either the DCON or the Modbus/TCP communication protocol.

| Module | Native SDK | .NET CF SDK |
|---------------|-------------|-------------|
| M-7000 series | Modbus Demo | Modbus Demo |
| I-8KE4/8-MTCP | Modbus Demo | Modbus Demo |

For more detailed information about ET-7000 and I-8KE4/8-MTCP series modules using Modbus protocol and its demos, please refer to:


http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/demo/nmodbus/

6. API Resources and Demo References

This chapter provides a brief overview of PAC standard APIs and demos that have been designed for VP-x231-CE7 from the PAC SDK package.


ICP DAS provides a set of demos in different programming languages. You can examine the demo codes, which includes numerous comments, to familiarize yourself with the PAC APIs. This will allow developing your own applications quickly by modifying these demo programs.

For full usage information regarding the description, prototype and the arguments of the functions, please refer to the “PAC Standard API Manual”



6.1. PAC Standard APIs for System Operation

The diagram below shows the set of each system operation API provided in the PACSDK.



6.1.1. VB.NET Demos for PAC Standard APIs

The PAC SDK includes the following demos that demonstrate the use of the PAC Standard APIs in a VB.NET language environment.

The following demos can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

CD:\vp-x231\Demo\PAC\Vb.net\Standard\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/demo/pac/vb.net/standard/

| Folder | Demo | Explanation |
|--------------|---------------------|--|
| system | systeminfo | Retrieves information about the OS version, CPU version, SDK version, etc. |
| backplane | backplaneinfo | Retrieves information about the DIP switch, backplane ID and slot count. |
| memoryaccess | memory | Shows how to read/write date values from/to EEPROM |
| | battery_backup_sram | Shows how to read or write to the battery backup |
| watchdog | watchdog | Displays how the watchdog operate |
| microsd | microsd_management | Shows how to enables/disables Micro SD |
| registry | registry | Shows how to read/write date values from/to registry |
| UART | diag | Shows how to read the name of local I/O modules via UART |

6.1.2. C# Demos for PAC Standard APIs

The PAC SDK includes the following demos that demonstrate the use of the PAC Standard APIs in a C# language environment.

The following demos can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

CD:\vp-x231\Demo\PAC\C#\Standard\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/demo/pac/c%23/standard/

| Folder | Demo | Explanation |
|-------------------|-------------------|---|
| buzzer | buzzer | Shows how to make a simple buzzer beep. |
| DeviceInformation | DeviceInformation | Retrieves information about the OS version, CPU version, SDK version, etc. |
| GetRotaryID | GetRotaryID | Retrieves information about the status of the rotary switch |
| Memory | Memory | Shows how to read/write data values from/to the EEPROM or the backplane of the SRAM |
| MultiRT | MultiRT | Shows how to manage the microSD |
| RealTimeTest | RealTimeTest | Writes the managed cod for the rich graphical user interface that does not require true real-time performance |
| Registry | Registry | Shows how to read/write data values from/to the registry |
| UART | UART | Shows how to read the name of a local I/O modules via a UART |
| WatchDog | WatchDog | Displays information about how to operate the watchdog |

6.1.3. Visual C++ Demos for PAC Standard APIs

The PAC SDK includes the following demos that demonstrate the use of the PAC Standard APIs in a Visual C++ language environment.

The following demos can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.


CD:\vp-x231\Demo\PAC\vc2008\Standard\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/demo/pac/vc2008/standard/

| Folder | Demo | Explanation |
|-------------------|-------------------|---|
| buzzer | buzzer | Shows how to make a simple buzzer beep. |
| DeviceInformation | DeviceInformation | Retrieves information about the OS version, CPU version, SDK version, etc. |
| GetRotaryID | GetRotaryID | Retrieves information about the status of the rotary switch |
| Memory | Memory | Shows how to read/write data values from/to the EEPROM or the backplane of the SRAM |
| MultiRT | MultiRT | Shows how to manage the microSD |
| RealTimeTest | RealTimeTest | Writes the managed cod for the rich graphical user interface that does not require true real-time performance |
| Registry | Registry | Shows how to read/write data values from/to the registry |
| UART | UART | Shows how to read the name of a local I/O modules via a UART |
| WatchDog | WatchDog | Displays information about how to operate the watchdog |

6.2. PAC Standard APIs for I/O Expansion

The diagram below shows the types of the PAC IO APIs provided in the PACSDK.



6.2.1. VB.NET Samples for PAC Standard APIs

The PAC SDK includes the following samples that demonstrate the use of the PAC IO APIs in a VB.NET language environment. The following samples can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

For VB.NET applications, these demo programs can be obtained from:

CD:\vp-x231\Demo\PAC\Vb.net\IO\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/demo/pac/vb.net/io/

| Folder | Demo | Explanation |
|--------|-------------|---|
| Local | find_io | Shows how to retrieve the module names and types which plugged in the VP-x231-CE7. |
| | 8k_di | Shows how to read the DI values of DI module. This demo program is used by 8K series DI modules. |
| | 8k_do | Shows how to write the DO values to DO module. This demo program is used by 8K series DO modules. |
| | 8k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 8K series DIO modules. |
| | 87k_basic | Shows how to send/receive a command/response application. This demo program is used by 87K series modules. |
| | 87K_demo | Shows how use UART API and the IO modules located as slots. This demo program is used by 87K series modules. |
| | 87k_ai | Shows how to read the AI values of AI module. This demo program is used by 87K series AI modules. |
| | 87k_ao | Shows how to write the AO values to AO module. This demo program is used by 87K series AO modules. |
| | 87k_di | Shows how to read the DI values of DI module. This demo program is used by 87K series DI modules. |
| | 87k_do | Shows how to write the DO values to DO module. This demo program is used by 87K series DO modules. |
| | 87k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 87K series DIO modules. |
| Remote | 7k87k_basic | Shows how to send/receive a command/response application. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_ai | Shows how to read the AI values of AI module. This demo program is used by 7K or 87K series |

| Folder | Demo | Explanation |
|--------|-----------|--|
| | | AI modules which connected through a COM port. |
| | 7k87k_ao | Shows how to write the AO values to AO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_di | Shows how to read the DI values of DI module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_do | Shows how to write the DO values to DO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |

6.2.2. C# Samples for PAC Standard APIs

The PAC SDK includes the following samples that demonstrate the use of the PAC IO APIs in a C# language environment. The following samples can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

For C# applications, these demo programs can be obtained from:

CD:\vp-x231\Demo\PAC\C#\IO\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/demo/pac/c%23/io/

| Folder | Demo | Explanation |
|--------|-------------|---|
| Local | find_io | Shows how to retrieve the module names and types which plugged in the VP-x231-CE7. |
| | 8k_di | Shows how to read the DI values of DI module. This demo program is used by 8K series DI modules. |
| | 8k_do | Shows how to write the DO values to DO module. This demo program is used by 8K series DO modules. |
| | 8k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 8K series DIO modules. |
| | 87k_basic | Shows how to send/receive a command/response application. This demo program is used by 87K series modules. |
| | 87K_demo | Shows how use UART API and the IO modules located as slots. This demo program is used by 87K series modules. |
| | 87k_ai | Shows how to read the AI values of AI module. This demo program is used by 87K series AI modules. |
| | 87k_ao | Shows how to write the AO values to AO module. This demo program is used by 87K series AO modules. |
| | 87k_di | Shows how to read the DI values of DI module. This demo program is used by 87K series DI modules. |
| | 87k_do | Shows how to write the DO values to DO module. This demo program is used by 87K series DO modules. |
| | 87k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 87K series DIO modules. |
| Remote | 7k87k_basic | Shows how to send/receive a command/response application. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_ai | Shows how to read the AI values of AI module. This demo program is used by 7K or 87K series |

| Folder | Demo | Explanation |
|--------|-----------|--|
| | | AI modules which connected through a COM port. |
| | 7k87k_ao | Shows how to write the AO values to AO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_di | Shows how to read the DI values of DI module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_do | Shows how to write the DO values to DO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |

6.2.3. Visual C++ Samples for PAC Standard APIs

The PAC SDK includes the following samples that demonstrate the use of the PAC IO APIs in a Visual C++ language environment. The following samples can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

For Visual C++ applications, these demo programs can be obtained from:

CD:\vp-x231\Demo\PAC\Vc2008\IO\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/demo/pac/vc2008/io/

| Folder | Demo | Explanation |
|--------|-------------|---|
| Local | find_io | Shows how to retrieve the module names and types which plugged in the VP-x231-CE7. |
| | 8k_di | Shows how to read the DI values of DI module. This demo program is used by 8K series DI modules. |
| | 8k_do | Shows how to write the DO values to DO module. This demo program is used by 8K series DO modules. |
| | 8k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 8K series DIO modules. |
| | 87k_basic | Shows how to send/receive a command/response application. This demo program is used by 87K series modules. |
| | 87K_demo | Shows how use UART API and the IO modules located as slots. This demo program is used by 87K series modules. |
| | 87k_ai | Shows how to read the AI values of AI module. This demo program is used by 87K series AI modules. |
| | 87k_ao | Shows how to write the AO values to AO module. This demo program is used by 87K series AO modules. |
| | 87k_di | Shows how to read the DI values of DI module. This demo program is used by 87K series DI modules. |
| | 87k_do | Shows how to write the DO values to DO module. This demo program is used by 87K series DO modules. |
| | 87k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 87K series DIO modules. |
| Remote | 7k87k_basic | Shows how to send/receive a command/response application. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_ai | Shows how to read the AI values of AI module. This demo program is used by 7K or 87K series |

| Folder | Demo | Explanation |
|--------|-----------|--|
| | | AI modules which connected through a COM port. |
| | 7k87k_ao | Shows how to write the AO values to AO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_di | Shows how to read the DI values of DI module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_do | Shows how to write the DO values to DO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |
| | 7k87k_dio | Shows how to read the DI and the DO values of the DIO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port. |

7. VP-x231-CE7 Updates


This chapter provides a guided tour that demonstrates the steps needed to update the VP-x231-CE7 OS and SDKs.

ICP DAS will continue to add additional features to VP-x231-CE7 SDK and OS in the future, so we advise you to periodically check the ICP DAS web site for the latest updates.

The file location of the OS and SDK

Both the files of OS updates and SDK updates can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.


CD:\vp-x231\
http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/




7.1. OS Updates

The latest version of the VP-x231-CE7 OS image can be found separately on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

CD:\vp-x231\
http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/




There are two ways to update the OS:



1. OS updates from eshell (Please refer to section 7.1.1)
(We recommend that you use this one for more quicker and easier to update)
2. OS updates from micro_SD (Please refer to section 7.1.2)

7.1.1. OS Updates from Eshell

By default, the OS update is updated via a LAN.
Before updating the OS, make sure the LAN is connected to PC.



Step 1: Get the latest version of the installation package file and then unzip it

The latest version of the installation package file can be found from ICP DAS web site.

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/os_image/vp-123x/update_from_eshell_or_micro_sd


Step 2: Run the registry clear.exe

The registry.exe can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

CD:\VP-x231\PC_Tools\Eshell

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/pc_tools/eshell/

Step 3: Place the rotary switch in position 3, OS update mode



Step 4: Run the ESHELL.exe, and then restart the VP-x231-CE7-CE7

The ESHELL.exe can be found on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.




CD:\VP-x231\PC_Tools\Eshell


http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/pc_tools/eshell/

Step 5: Select the device which you want to update the OS image, and then click OK


Select the device name which you want to update the OS image from the list.




Step 6: Select the latest version of the OS image file



Step 7: Once the procedure is completed, the “Warning !” dialog box will appear as below shown, then turn the rotary switch in position 0, normal mode




Step 8: Click the OK button



Step 9: Check the OS version

Run the PAC Utility, and then select the Device Information tab to check the current OS version.




7.1.2. OS updates using micro_SD

The microSD card can be used to reinstall the VP-x231-CE7 OS image to factory default settings in the event of the VP-x231-CE7 failure.


Step 1: Get the latest version of the installation package file, then unzip the file, and then copy them to microSD card

The latest version of the installation package file can be found from ICP DAS web site.



http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/os_image/vp-123x/update_from_eshell_or_micro_sd/



Step 2: Plug the microSD card into microSD slot




Step 3: Turn the rotary switch in position 5, OS update mode



Step 4: Reboot the VP-x231-CE7




Step 5: Wait a few minutes for the following desktop to be displayed




Step 6: Turn the rotary switch in position 0, normal mode

Step 7: Reboot the VP-x231-CE7



Step 8: Check the OS version

Run the PAC Utility, and then select the Device Information tab to check the current OS version.




7.2. SDK Updates

SDK update is a part of the VP-x231-CE7 update services to provide additional and more efficient features and functionality for VP-x231-CE7 operating system.

The SDK update files can be found separately on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

CD:\vp-x231\SDK\

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/sdk/



7.2.1. SDK Updates for VB.NET or C#

The SDK can be updated by changing the SDK file.

Step 1: Get the latest version of the PACNET.dll file

The latest version of the PACNET.dll file can be obtained from ICP DAS web site.

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/sdk/pacnet/

Step 2: Copy the latest version of PACNet.dll file to PC and VP-x231-CE7

The PACNET.dll file on PC can be placed anywhere only the solution can reference it.

The PACNET.dll file on VP-x231-CE7 is located at the same directory as the .exe file.

7.2.2. SDK Updates for VB.NET or Visual C++

The SDK can be updated by changing the SDK file.

Step 1: Get the latest version of the VC++ components

The latest version of the VC++ components can be obtained from:

http://ftp.icpdas.com/pub/cd/winpac_am335x/vp-x231/sdk/pacsdk/

Step 2: Copy the latest version of header files and libraries to PC

The header files are located at:

C:\Program Files\Windows CE Tools\SDKs\AM335x_WINCE7_SDK\Include\Armv4i

The libraries are located at:

C:\Program Files\Windows CE Tools\SDKs\AM335x_WINCE7_SDK\Lib\ARMv4I

Step 3: Copy the latest version of DLL files to VP-x231-CE7

The DLL files are located at:

\System_Disk\ICPDAS\System

8. ViewPAC Download Center

This chapter provides a brief introduction of the ViewPAC download center.

ViewPAC has a download center where you can access the latest version of the software, tools, demo programs, and related information.


The ViewPAC Download Center can be found at:

http://www.icpdas.com/root/support/download/pac/vp-x23x-ce7/vp-x23x-ce7_download_os_images.html

VP-x23x Download Center

Note:

When you download the software programs, you should notice if the programs conform to your machine. Before you download any program, please read the notes of each online program first to avoid the confused situation.



The screenshot shows a web interface with a navigation bar containing tabs for OS images, SDK, Utility & Tools, Demo, Documents, System Disk, and FAQ. The main content area is titled "OS images download" and includes a note about compatibility. Below this, there is a section for "VP-123x OS Image" with version information and download options for Micro_SD and eshell.

OS images SDK Utility & Tools Demo Documents System Disk FAQ

OS images download


Note:
Before you download the software programs, you should notice if the programs are compatible to your machine. **Please read the notes first in each chapter you want before download programs.**

Note: User can check the OS image version by PAC Utility -> System Information-> OS version

VP-123x OS Image

Version: 1.0.1.1 (Released at Dec. 2015)

OS image update by Micro_SD (copy file to Micro_SD of VP-1231)

VP123x_20151216_ver.1.0.1.1_ml.zip (Multi-lingual) 

OS image update from eshell

VP123x_20151216_ver.1.0.1.1_ml.zip (Multi-lingual)

Tips & How to

This chapter provides tips and a guided tour on using and maintaining the VP-x231-CE7.

A. I-8K and I-87K I/O Modules

There are 3 slots to expand local I/O. And the I/O modules can be parallel bus type (high profile I-8K series) and serial bus type (high profile I-87K series).


The difference between them is as follows:

| Functions | I-8K Series | I-87K Series |
|--|--------------|--------------|
| Communication interface | Parallel bus | Serial bus |
| Protocol | - | DCON |
| Communication speed | Fast | Slow |
| DI latched function | - | Yes |
| Counter input (for digital input module) | - | Yes (100 Hz) |
| Power on value | - | Yes |
| Safe value | - | Yes |
| Programmable slew-rate for AO module | - | Yes |

B. How to Change the Battery

RTC and SRAM data is retained by two Li batteries, which can supply continuous power to the 512 KB SRAM to ensure that the data is retained for 5 years. The dual-battery design has the added function of preventing data from being lost while replacing the battery.

The following figures show the location of the two batteries installed in the ViewPAC.



To checking the current battery power:

1. Run the PAC utility and check the Battery1 and Battery2 fields that display the current status of each battery. Refer to Section 3.1.3. PAC Utility - Property Tab - General for more details. If the power level for either of the batteries is low, both should be replaced.
2. When programming this, call the `pac_GetBatteryLevel()` API function in the PACSDK.dll to check whether the battery power is low. When the power for either of the batteries is low, it's recommended that the battery is replaced immediately, otherwise the data on the SRAM may be lost or RTC time will be reset.

Tips & Warnings



The battery initial voltage should be around 2.8 V to 3.0 V. When lower than 2.1 V, the PAC Utility will show the low power warning. When lower than 1.5 V, the data in the RTC (real time clock) and 512 KB SDRAM will be lost.

To replace the battery without losing data:

1. Power off the ViewPAC.
2. Remove the slot cover and I/O socket inserted into the slot.
3. First, remove the battery that is running low on power from the battery holder.
4. Insert a new battery.
5. Remove the other battery.
6. Insert a new battery.

Tips & Warnings



1. If the battery power for only one of the two batteries is low, you can use this method to replace the battery so as to prevent data from being lost. (In the circuit design for the ViewPAC series, when the power for one of the batteries is low, it will automatically switch to the other one to ensure continued battery power)
 2. If both batteries have run out of power, the data will be lost, even if this method is used to replace the batteries.
-

To replace the battery 1/2:

To back up the SRAM data using the backup utility before replacing the battery. Refer to Section “Using the Backup Utility to back up the settings and files” to back up and restore the SRAM data.

1. Run the backup utility to back up the SRAM data.
2. Power off the ViewPAC.
3. Remove the slot cover and I/O socket inserted into the slot.
4. Remove both batteries from their respective holders.
5. Insert a new battery.
6. Power on the ViewPAC.
7. Run the backup utility to restore the SRAM data.
8. Set the RTC time.

C. How to Online Debug the VP-x231-CE7 Program

Here are step by step instructions on how to online debug the VP-x231-CE7 program.

Tips & Warnings



Before starting online debug the VP-x231-CE7 program, make sure that the VP-x231-CE7 SDK has been installed correctly.


For more information on how to install the VP-x231-CE7 SDK, please refer to 4.1.2. Installing the VP-x231-CE7 SDK.

Step 1: Copy the following files to the \System_Disk\icpdas\system on the VP-x231-CE7


By default, these files are located on the development computer at C:\Program Files\Common Files\Microsoft Shared\CoreCon\1.0\Target\wce400\<CPU>.

- clientshutdown.exe
- CMAccept.exe
- ConmanClient2.exe
- eDbgTL.dll
- TcpConnectionA.dll

Step 2: Run the ConmanClient2.exe and then CMAccept.exe on the VP-x231-CE7




Step 3: On the Tools menu, click the Options




Step 4: In the left pane, expand Device Tools node and select Devices


Step 5: In the Show devices for platform:, select AM335x_WINCE7_SDK and then click Properties





Step 6: Click the Configure...




Step 7: Select the Use specific IP address:, and then type the IP address of VP-x231-CE7




Step 8: Click the OK, and then click OK to end the dialog



Step 9: On the Tools menu, click the Connect to Device...




Step 10: Wait for the connection to be established



Tips & Warnings



If the connection fails, as shown below, please repeat the step 2 to step 9 to try it again.




D. How to Automatically Synchronize VP-x231-CE7 Clock with an Internet Time Server

The clock on the VP-x231-CE7 can be synchronized with an internet time server. This means that the clock is updated to match the clock on the time server, which can help ensure that the time on the VP-x231-CE7 is accurate. Here are step by step instructions on how to synchronize the clock on the VP-x231-CE7 with an Internet time server.

Step 1: Run the PAC Utility




Step 2: On the General tab, press Configure button




Step 3: Select the domain name from the Server drop-down list, and then enter a value in the Autoupdate Frequency field

Step 4: Check the Automatically synchronize with an internet time server check box




Step 5: On the File menu, click Save and Reboot



Step 6: The VP-x231-CE7 will automatically synchronize with an internet time server regularly

Step 7: Click the Update Now button to synchronize VP-x231-CE7 clock immediately



E. How to Control the User Account Control in VP-x231-CE7

User Account Control is a security feature that helps prevent unauthorized system changes to the VP-x231-CE7.


E.1. How to Create a User Account

Here are step by step instructions on how to add a user account.


Step 1: Run the PAC Utility




Step 2: On the Login tab of the Network tab, click Login tab, type the User Name and Password, and then click Add button



Step 3: The user has been added to the allowed under the remote login and included in the following list




Step 4: On the File menu, click Save and Reboot for changes to take effect




E.2. How to Use Telnet to Remote Login the ViewPAC from PC

Here are step by step instructions on how to use telnet to remote login the ViewPAC from PC.


Step 1: On the PC, open a MS-DOS command prompt




Step 2: At the command prompt, type "telnet (IP address)"



Step 3: The connection has been set up, and then type the name and password




Step 4: The remote login has been completed




E.3. How to Remove a User Account from the Login List

Here are step by step instructions on how to remote the user from the login list.

Step 1: Click a user from the list which you want to remove, and the user will display in the field, and then press Delete to delete the user from the login list




Step 2: On the File menu, click Save and Reboot for changes to take effect



F. How to Use the Services Tool

The services tool can help you turn on, turn off and monitor the WinCE services.

Step 1: On the PC, open a MS-DOS command prompt



Step 2: List all services

[Syntax] services list

```
File Edit Help
Pocket CMD v 5.0
\> services list
NFYO: 0x00030110 NOTIFY.Dll Running
HTPO: 0x00031570 HTTPD.DLL Running
CRDO: 0x00032070 credsvc.dll Running
MMQ1: 0x00036790 MSMQD.Dll Off
OBX0: 0x00036b20 OBEXSrVr.dll Off
FTPO: 0x00037770 FTPD.Dll Running
TELO: 0x00037ac0 TELNETD.Dll Running
SMB0: 0x0003c3e0 smbserver.dll Running
NTPO: 0x0003fff0 timesvc.dll Running
\>
```

Step 3: Type the commands to configure service

[Syntax] services stop <services name>

For example, turn on the “FTP” service:

services stop FTP0:

```
File Edit Help
Pocket CMD v 5.0
\> services stop FTP0:
\> services list
NFYO: 0x00030110 NOTIFY.Dll Running
HTPO: 0x00031570 HTTPD.DLL Running
CRDO: 0x00032070 credsvc.dll Running
MMQ1: 0x00036790 MSMQD.Dll Off
OBX0: 0x00036b20 OBEXSrVr.dll Off
FTP0: 0x00037770 FTPD.Dll Off
TELO: 0x00037ac0 TELNETD.Dll Running
SMB0: 0x0003c3e0 smbserver.dll Running
NTP0: 0x0003fff0 timesvc.dll Running
\>
```

Tips & Warnings



For more information about using services tool, just type “services help”

```
File Edit Help
Pocket CMD v 5.0
\> services help
Commands:
    help - print this text
    list - lists loaded services
    load <service name> - activates a service that is inactive
    stop <service instance> stops/pauses a service (does not unload)
    start <service instance> - starts/resumes a service
    refresh <service instance> - causes service to refresh its config
    unload <service instance> - causes service to be unloaded and
    register <service name> - service will be automatically loaded
eboot
    unregister <service name> - service will not be automatically
next reboot
    command <service name> [arg1 arg2 ...] - send service-specific
o service
    help <service name> - get information on what service-specific
are supported

    <service name> - service's name in the registry (i.e. HTTPD)
    <service instance> - particular instantiation (i.e. HTPO:)

Flags:
    -f <file name>
    -s silent
    -d output to debugger
\>
```

G. Application of RS-485 Network

The RS-485 length can be up to 4000 ft or 1.2 km over a single set of twisted-pair cables, if the RS-485 network is over 4000 ft or 1.2Km, the RS-485 repeater must be added to extend the RS-485 network.

G.1. Basic RS-485 Network

The basic component of the RS-485 network consist of a Master Controller (or using a PC as a host controller), and some RS-485 devices.


Tips & Warnings



If PC/Laptop has no COM port, you can use the I-7561 (USB to RS-485 converter) for connection between ViewPAC and PC/Laptop.


Before using the I-7561 converter, you must install the USB driver. The USB driver can be obtained from:

<ftp://ftp.icpdas.com/pub/cd/8000cd/napdos/7000/756x/>




G.2. Daisy Chain RS-485 Network

All RS-485 devices are wired directly to the main network. If the network is up to 1.2 km, a repeater (7510 series) is required to extend the length of the network.




G.3. Star Type RS-485 Network

There are branches along the main network. In this case, it is better to have a repeater to isolate or filter the noise that is made by devices.




There is a better choice to use 7513 as a RS-485 hub on start type network.



G.4. Random RS-485 Network

There are branches along the main wire. In this case, it is better to have a repeater to isolate or filter the noise that is made by devices.





G.5. Master/Slaves Settings

There must be exist one master to have a jumper in the same network. In a master/slave application, "Master" is the default configuration of ViewPAC.

G.5.1. ViewPAC as a Master (default)



When one of ViewPAC is set to the master mode, then all the other devices on the same network must be set to the slave mode.

Set ViewPAC to the master mode by adjusting the jumpers on the PCB board of ViewPAC. Refer to the following figure:




G.5.2. ViewPAC as a Slave:

Set ViewPAC to the slave mode by adjusting the jumpers on the PCB board of ViewPAC. Refer to the following figure:




The maximum distance of RS-485 without using a repeater is 1,200 meters (4,000 feet). You can extend that distance by adding an RS-485 Repeater every 1,200 meters as shown below.




G.6. 120Ω Terminating Resistor Settings

The built-in 120Ω terminating resistor is for RS-485 network communication, and is disabled as factory default setting. If the total length of the communication bus longer than 100 m, terminating resistors is recommended to be placed at both far ends of the cable.




■ RS-485 bus < 100m



| Module | Master | Slave #1 | Slave #2 | Slave #3 |
|--------|--|-----------------------------------|-----------------------------------|-----------------------------------|
| S2 | <p>Master</p> <p>Slave</p> | <p>Master</p> <p>Slave</p> | <p>Master</p> <p>Slave</p> | <p>Master</p> <p>Slave</p> |
| S3 | <p>NC</p> <p>120R</p> | <p>NC</p> <p>120R</p> | <p>NC</p> <p>120R</p> | <p>NC</p> <p>120R</p> |

■ RS-485 bus > 100m



| Module | Master | Slave #1 | Slave #2 | Slave #n |
|--------|--|-----------------------------------|-----------------------------------|-----------------------------------|
| S2 | <p>Master</p> <p>Slave</p> | <p>Master</p> <p>Slave</p> | <p>Master</p> <p>Slave</p> | <p>Master</p> <p>Slave</p> |
| S3 | <p>NC</p> <p>120R</p> | <p>NC</p> <p>120R</p> | <p>NC</p> <p>120R</p> | <p>NC</p> <p>120R</p> |

H. Revision History

This chapter provides revision history information to this document.

The table below shows the revision history.

| Revision | Date | Description |
|----------|---------------|---|
| 1.0.0 | December 2015 | Initial issue |
| 1.0.1 | May 2016 | Added the product information about VP-4231-CE7 and VP-6231-CE7. |
| 1.0.2 | December 2016 | Modified the installation information in section 2.1.1, 2.1.2. and 2.1.3. |